


Eyeball Network Camera Installation Guide

V1.0.0

1.2.51.32.15631-000



Optional

1. Camera with optional lens.
2. Camera with optional lens and mounting ring.
3. Camera with optional lens and mounting ring, showing a PH1 screwdriver and a RESET button.

A

1. Drill a hole in the ceiling.
2. Insert the mounting bracket into the hole.
3. Connect the camera to the bracket.
4. Tighten the screws to secure the bracket.
5. Mount the camera onto the bracket.
6. Final camera installation.

B

1. Drill a hole in the ceiling.
2. Insert the mounting bracket into the hole.
3. Connect the camera to the bracket.
4. Tighten the screws to secure the bracket.
5. Mount the camera onto the bracket.
6. Final camera installation.

a

1. Strip the outer jacket of the cable.
2. Strip the individual conductors.
3. Insert the conductors into the RJ45 connector.
4. Push the conductors into the RJ45 connector.

b Optional

1. Strip the outer jacket of the cable.
2. Strip the individual conductors.
3. Insert the conductors into the RJ45 connector.
4. Push the conductors into the RJ45 connector.
5. Push the RJ45 connector into the camera's port.

